

# Rittal – The System.

Faster – better – everywhere.

## ► Levelling feet with internal adjustment, for VX IT – VX 5301.326

Date : Jun 23, 2021

ENCLOSURES

POWER DISTRIBUTION

CLIMATE CONTROL

IT INFRASTRUCTURE


SOFTWARE & SERVICES

FRIEDHELM LOH GROUP



# Levelling feet with internal adjustment, for VX IT – VX 5301.326

created: 23.06.2021 on [www.rittal.com/com-en](http://www.rittal.com/com-en)



## Product description

**Description:** To compensate for floor irregularities. When used in the mounting bracket, the levelling feet are moved inwards to allow convenient operation from inside the enclosure so that the enclosure is easily levelled, even retrospectively.

**Supply includes:** 4 levelling feet, M12, with TX30 hex socket drive  
4 mounting brackets  
Assembly parts

**Note:** Use levelling foot 4612.000 and base/plinth adaptor 8100.770 for mounting on the VX base/plinth

## Product description

**To fit:** Enclosure type: VX IT

**Load capacity:** Max. admissible static load: 6,500 N per levelling foot

**Packs of:** 4 pc(s).

**Weight/pack:** 0.8 kg

**Copper weight (kg per piece):** 0

**EAN:** 4028177952478

**Customs tariff number:** 73269098

<b>ETIM 7.0:</b>	EC000721
<b>ETIM 6.0:</b>	EC000721
<b>eCl@ss 8.0/8.1:</b>	27182003
<b>eCl@ss 6.0/6.1:</b>	27182003
<b>Product description:</b>	Levelling foot, M12, with internal adjustment, for VX IT, to compensate for height differences in the event of floor unevenness, for fastening in the die-cast zinc feet of the base/plinth.