

Airtame: Making screens smarter

Wireless screen sharing and digital signage for education and enterprise

- Airtame 2 (AT-DG2)
- Airtame Cloud Plus (AT-CLOUD-PLUS-1)
- PoE Adapter (AT-POE)
- Ethernet Adapter (AT-ETH)
- Extension Cord (AT-IEC-EU/UK/US)

Airtame 2

The Airtame 2 offers wireless presentations from any device, digital signage for all screens, and all-in-one cloud management.

Install: Equip your TV, projector, monitor or smartboard with an Airtame 2 to make your screen smarter with cross-platform, wireless streaming. Connect the Airtame 2 via HDMI and power it with an AC adapter or optional Power Over Ethernet adapter (POE).

Present: Connect your way, with the choice between the Airtame desktop app, Google Cast, AirPlay, or Miracast.

Manage: View, update and manage all devices at once and from anywhere with the [Airtame Cloud](https://airtame.cloud/) remote management platform (<https://airtame.cloud/>).

Features

Install

- Easy and flexible installation. The Airtame 2 includes a magnet mount and an adhesive seal allowing users to quickly fix the Airtame on any surface. No complex or time-consuming installation required.
- Physical security. The Airtame 2 incorporates a Kensington lock slot to physically secure the Airtame.
- Secure within any network. Airtame integrates with WPA2-Enterprise,

SSL certificates, and Proxy Networks.

- Flexible network integration. Airtame works across multiple networks and VLANs, allowing guests and internal users to connect to the Airtame in a secure manner. The Airtame also broadcasts its own SSID, which means you can connect directly to the device and use your Airtame as a guest access point.
- PoE and Ethernet adapter available. Set up & installation video: <https://www.youtube.com/watch?v=OrPz6jMkBaE>

Present

- Cross-platform. Present wirelessly from any computer or mobile device running Windows, macOS, ChromeOS, Linux, iOS or Android.
- Flexible sharing options. Present using the Airtame desktop app or Google Cast, Miracast and AirPlay.
- Presenter mode. Mirror your full screen or use presenter mode with Single Window Sharing
- Multiple displays. Share to one or many displays simultaneously with the Airtame desktop app
- Quality streaming. Enjoy full HD streaming at up to 60 fps.
- Dedicated video and audio mode. Activate video mode to enjoy better video quality, fluid playback, and audio-video synchronization.
- Pin code connect. Guarantee that presenters share to the correct display (and prevent unwanted streams).

Manage

- Cloud management. Manage, monitor and configure all your devices from one central location, remotely and collectively using [Airtame Cloud](https://airtame.cloud/) (<https://airtame.cloud/>).
- Unlimited number of users and devices. Add all of your Airtame 2 devices across locations to the same Airtame Cloud account, and invite as many users as needed.
- Control user roles & permissions. Invite colleagues to collaborate and assign different access levels depending on user roles, location and use case.
- Optimal deployment. Equip the IT administrators with full control over device performance and settings
- Free software and firmware updates.

Looking for information regarding Airtame's digital signage platform? Check Airtame Cloud Plus. ([link to Airtame Cloud product page](#))

Why Airtame 2?

- One unified platform. Wireless screen sharing, digital signage and device management.
- Designed for professional and educational environments.
- Multi-platform / BYOD. Compatible with all devices, all operating systems and native casting protocols.
- Centralized and remote management via the [Airtame Cloud](#) platform.
- Free software and hardware updates.

Airtame in 30 seconds video: <https://www.youtube.com/watch?v=uTLHmJcch2g>

Airtame Cloud Plus

Airtame Cloud Plus lets you easily and remotely manage the digital signage content displayed on your screens by Airtame 2.

Features

- Remote digital signage content management. Real-time overview and management of your Airtame devices and the signage content showing on your screens.
- Create tailored digital signage. Display images, videos, websites, schedules, room agendas, clocks, project progress and more.
- Preview content. Ensure you're sharing the right content on screen by previewing it first in the Airtame Cloud app.
- Meeting room scheduling. Display an overview of the room booking and schedule in meeting rooms and classrooms. Fully integrated with Office 365 and G-suite meeting room calendars.
- Integrations with applications including YouTube, Google Calendar, Outlook Calendar, Dropbox, Microsoft OneDrive and more

- Set up playlists. Schedule imagery and videos to play on loop with the Playlists feature.
- Screen orientation. Possibility to display signage content on portrait or landscape mode.
- Save on power. Automate your screens to turn on and off according to office or school hours with Sleep Schedule.

Why Airtame Cloud Plus?

- Eliminate point solutions. Simplify troubleshooting and reduce IT maintenance with one solution for all screens and remote signage management.
- Improve internal communication. Tailor screens with relevant digital signage for colleagues, students and visitors.
- Assign user roles. Invite colleagues to manage signage content autonomously.

In order to run signage content on a screen with Airtame Cloud Plus plan, it is required to have the Airtame 2 device installed on the chosen screen, and on the network. ([link to Airtame 2 product page](#))

Airtame Cloud video: <https://www.youtube.com/watch?v=hxi4I0YBtXk>

Airtame PoE adapter

The Airtame PoE Adapter lets you power your Airtame 2 through a PoE connection over USB. Together with our Aircord and a PoE-enabled network, you have a 3-in-1 solution that powers your Airtame, connects it to your network, and plugs into your display screen's HDMI. ([link to Airtame PoE product page](#))

Benefits

- Boost network performance. Increase your network speed by up to 5 times than with the Airtame Ethernet adapter.
- No extra installation. Use your pre-existing Ethernet cable infrastructure and avoid complex electrical installation.
- Save money. Skip the expensive electrician. With PoE, you save installation and infrastructure maintenance costs.

- Clean and simple set-up. Easy and fast to install. Create the ultimate cable clutter-free environment.

How to set up Airtame PoE adapter video:

<https://www.youtube.com/watch?v=9ly4xOZQBII>

Airtame Ethernet adapter

The Airtame Ethernet adapter lets you hardwire your Airtame device for a stable network connection. The adapter plugs into the Airtame micro-usb port and allows the device to be hardwired to your network via an ethernet cable.

If you need power and a wired network connection in one, check the Airtame PoE adapter.

Airtame Extension Cord The Airtame Extension Cord extends the range of Airtame's power supply unit by 1.8m/6ft. Not necessary when Airtame PoE Adapter is used.