

## **Technical Accessory Guides (TAGs)**

For Associates, Resellers, ISVs and Alliance Partners
Global



Version: Active-Only
Will only show products that are known to be available for sale

Need to provide an update or change? Contact mailto:pgw786@zebra.com







## RS5100 Series Technical Accessory Guide



NOTE: This document is only for general reference. Solutions Pathway and related PMBs should be used for product availability, pricing, and final solution selection.

\* Zebra does not endorse or specifically recommend any third-party products, accessories, or hardware. ZEBRA DISCLAIMS ANY AND ALL LIABILITY, INCLUDING ANY EXPRESS OR IMPLIED WARRANTIES, WHETHER ORAL OR WRITTEN, FOR SUCH THIRD PARTY PRODUCTS, ACCESSORIES, OR HARDWARE. THE CUSTOMER ACKNOWLEDGES THAT NO REPRESENTATION HAS BEEN MADE BY ZEBRA AS TO THE FITNESS OF THE THIRD-PARTY PRODUCTS, ACCESSORIES, OR HARDWARE FOR THE CUSTOMER'S INTENDED PURPOSE.

Cradles/Charging	Cradles/Charging					
Part Number	Picture	Description	Notes	Required Items		
CRD-RS51-4SCHG-01		4-Slot Charging ShareCradle	► Will charge up to 4 RS5100 units.  ► NOTE: Requires trigger assembly with charge contacts to be attached to RS5100. The charge contacts are part of the trigger assembly. If trigger assembly will be removed in between use, recommend using 8-Slot Battery Charger (SAC-RS51-8SCHG-01) instead.	► Power Supply (PWR-BGA12V50W0WW ► DC Line Cord (CBL-DC-388A1-01) ► AC Line Cord (23844-00-00F or country specific version)		
CRD-RS51-20SCHG-01		20-Slot Charging ShareCradle	▶ Will charge up to 20 RS5100 units. ▶ Can be racked/ mounted in a standard 19 inch rack system via the mounting accessory (BRKT-SCRD-SMRK-01). ▶ NOTE: Requires trigger assembly with charge contacts to be attached to RS5100. The charge contacts are part of the trigger assembly. If trigger assembly will be removed in between use, recommend using 8-Slot Battery Charger (SAC-RS51-8SCHG-01) instead.	►Power Supply (PWR-BGA12V108W0WW) ►DC Line Cord (CBL-DC-381A1-01) ►AC Line Cord (23844-00-00F or country specific version)		
SAC-RS51-8SCHG-01		8-Slot Battery Charger	► Will charge up to 8 spare batteries.	► Power Supply (PWR-BGA12V50W0WW ► DC Line Cord (CBL-DC-388A1-01) ► AC Line Cord (23844-00-00F or country specific version)		
KT-RS51-8SAC-PS-CB		8-Slot Battery Charger KIT	► Will charge up to 8 spare batteries.  ► Kit includes:  - 8-Slot Battery Charger (SAC-RS51-8SCHG-01)  - Power Supply (PWR-BGA12V50W0WW  - DC Line Cord (CBL-DC-388A1-01)  - AC Line Cord (23844-00-00R)  ► NOTE: This is a custom product.  Please work with your Zebra representative to open a Custom Product Request (CPR) if you would like to order this item.			

SAC-RS51-40SCHG-01		40-Slot Battery Charger	► Will charge up to 40 spare batteries.  ► Can be racked/ mounted in a standard 19 inch rack system via the mounting accessory (BRKT-SCRD-SMRK-01).	► Power Supply (PWR-BGA12V108W0WW) ► DC Line Cord (CBL-DC-381A1-01) ► AC Line Cord (23844-00-00F or country specific version)
BRKT-SCRD-SMRK-01		Multi-Slot Wall/Rack Mount Bracket	▶ Allows for rack and wall mounting of one 20-Slot Charging Cradle or 40-Slot Spare Battery Charger. Also can be used to mount up to four 4-Slot Chargers or 8-Slot Battery Chargers ▶ Bracket can be mounted on standard 19" network rack or on a wall. ▶ Cable routing slots & removable power supply holder tray. ▶ Adjustable tabs & screw mounts for easy hanging/installation. ▶ Adjustable orientations - horizontal, vertical, angled. ▶ See the Bluetooth-Generic Accessories TAG for info on 3rd party Network Racks that can be used for mounting this bracket.	
ADP-TC7X-PLT-FX		5-Slot ShareCradle Mounting Bracket Adapter Plate for Honeywell	▶ Allows Zebra Multi-Slot ShareCradles to be mounted on legacy Honeywell Flex Cradle Wall Mount Brackets (HON SKU #203-641-002). ▶ Includes hardware to attach plate to HON wall bracket and secure ShareCradle to plate. ▶ NOTE: This is a custom product. Please work with your Zebra representative to open a Custom Product Request (CPR) if you would like to order this cable.	
STB3678-C100F3WW STB3678-C100F3CN (for use in mainland China only)	THE WARREN TO STATE OF THE PARTY OF THE PART	Communication Cradle	► Allows RS5100 to be easily connected with hosts that do not have a Bluetooth radio for direct communication. ► Pairing barcode on Cradle is scanned to instantly pair with the RS5100. ► Up to 7 scanners can be paired per cradle.	► Host communication cable and possibly a power supply depending on the host cable type.  See 36XX Series Scanner accessory document for cable and power supply options
FLB3678-C100F3WW FLB3678-C100F3CN (for use in mainland China only)	THE STATE OF THE S	<b>Sealed</b> Communication Cradle	► Allows RS5100 to be easily connected with hosts that do not have a Bluetooth radio for direct communication.     ► Pairing barcode on Cradle is scanned to instantly pair with the RS5100.     ► IP65 sealed for installations requiring wash-down (i.e. forklift installations).     ► Up to 7 scanners can be paired per cradle.	► Host communication cable and possibly a power supply depending on the host cable type.  See 36XX Series Scanner accessory document for cable and power supply options

Communication Cables				
Part Number	Picture	Description	Notes	Required Items
CBL-TC5X-USBC2A-01		USB-C cable	► Cable can be used to charge and communicate to RS5100 units with Double Trigger Assembly with USB-C port (SG-RS51-TRGDU-01).  ► USB-A to USB-C cable  ► Cable length is 1M (~3.25 ft.)	For charging via AC Wall Outlet: USB Power Adapter (PWR- WUA5V12W0US - or country specific version)
3rd party *		USB-C cable	► Cable can be used to charge and communicate to RS5100 units with Double Trigger Assembly with USB-C port (SG-RS51-TRGDU-01).	For charging via AC Wall Outlet: USB Power Adapter (PWR- WUA5V12W0US - or country specific version)
Trigger Assemblies				
Part Number	Picture	Description	Notes	Required Items
SG-RS51-TRGSS-02		Trigger Assembly - Single Sided Trigger	▶ Provides a single large trigger button that can be rotated to be used with left or right handed operation. ▶ Trigger can be switched from right hand to left hand triggering by removing trigger assembly and reinstalling in opposite orientation. ▶ Provides large sized trigger button. ▶ Provides large sized trigger button. ▶ Charge contacts on assembly allow RS5100 to be inserted into 4-Slot Charging ShareCradle. ▶ Assembly includes: - one Single Sided Trigger (SG-RS51-TRGSNG-01) - single Strap for Single Trigger configuration (SG-RS51-STRPNY-10) - single Comfort Pad for Single Trigger assembly (SG-RS51-CMPD-01) - Stop screw (48-261663-01) that can be optionally used to prevent the trigger from being removed. ▶ Trigger's Strap has thicker metal U pir which provides increased pull force vs. SG-RS51-TRGSS-01.	

SG-RS51-TRGDS-01	Trigger Assembly - Double Sided Trigger	<ul> <li>▶ Provides two medium size trigger buttons - one on left and one on right side.</li> <li>▶ Charge contacts on assembly allow RS5100 to be inserted into 4-Slot Charging ShareCradle.</li> <li>▶ Trigger uses double rubber arm finger band. This finger-band is designed to be used bare-fingered or with lightweight gloves. The Single Sided Trigger is recommended if heavier weight gloves will be used.</li> </ul>	
SG-RS51-TRGDV-01	Trigger Assembly - Double Sided Trigger with Vibrator option	▶ Provides two medium size trigger buttons - one on left and one on right side. ▶ Charge contacts on assembly allow RS5100 to be inserted into 4-Slot Charging ShareCradle. ▶ Vibrator provides haptic feedback to user. ▶ Trigger uses double rubber arm finger band. This finger-band is designed to be used bare-fingered or with lightweight gloves. The Single Sided Trigger is recommended if heavier weight gloves will be used.	
SG-RS51-TRGDU-01	Trigger Assembly - Double Sided Trigger with USB-C port option	▶ Provides two medium size trigger buttons - one on left and one on right side. ▶ Charge contacts on assembly allow RS5100 to be inserted into 4-Slot Charging ShareCradle. ▶ USB-C port on assembly allows RS5100 to be charged via USB cable and also allows for programming using Zebra 123Scan application. ▶ Trigger uses double rubber arm finger band. This finger-band is designed to be used bare-fingered or with lightweight gloves. The Single Sided Trigger is recommended if heavier weight gloves will be used.	

SG-RS51-BHMT-02	Trigger Assembly - Back of Hand Adapter	▶ Allows RS5100 to be worn on the back of hand and provides remote finger trigger ▶ Mount is not a glove. Can be worn without gloves or over standard, low-cost gloves. ▶ Durable materials which resists wear – only the wrist strap is fabric. ▶ Long trigger lifecycle (millions of presses). ▶ One-size-fits-all and ambidextrous. ▶ Includes Strap for Back of Hand Mount, MEDIUM size (SG-RS51-BHSTP-02). ▶ NOTE: Does not include charge contacts on assembly, therefore not compatible with 4-Slot Charging ShareCradle (CRD-RS51-4SCHG-01). Use 8-Slot Battery Charger (SAC-RS51-8SCHG-01) or 40-Slot Battery Charger (SAC-RS51-40SCHG-01) instead.	
SG-RS51-BHMT-01	Trigger Assembly - Back of Hand Adapter	➤ Allows RS5100 to be worn on the back of hand and provides remote finger trigger  ➤ Mount is not a glove. Can be worn without gloves or over standard, low-cost gloves.  ➤ Durable materials which resists wear – only the wrist strap is fabric.  ➤ Long trigger lifecycle (millions of presses).  ➤ One-size-fits-all and ambidextrous.  ► Includes Strap for Back of Hand Mount, MEDIUM size (SG-RS51-BHSTP-01).  ➤ NOTE: Does not include charge contacts on assembly, therefore not compatible with 4-Slot Charging ShareCradle (CRD-RS51-4SCHG-01). Use 8-Slot Battery Charger (SAC-RS51-8SCHG-01) or 40-Slot Battery Charger (SAC-RS51-40SCHG-01) instead.	

EMC Product Line - RS5100 TAG Document Update date: 6/30/22

Right Hand mount SG-RS51-HNMTRL-01 (Large size - blue) SG-RS51-HNMTRM-01 (Medium size - black) SG-RS51-HNMTRS-01 (Small size - white)  Left Hand mount SG-RS51-HNMTLL-01 (Large size - blue) SG-RS51-HNMTLM-01 (Medium size - black) SG-RS51-HNMTLS-01 (Small size - white)		Trigger Assembly - Enterprise Hand Mount Adapter	Allows RS5100 to be worn on the back of hand and provides thumb trigger.  ▶ Mount is not a glove. Can be worn without gloves or over work gloves.  ▶ Provides a perfect fit for every worker with small, medium and large sizes for right and left hand usage. Allows adjustability of both the position of the scanner on the back of the hand and the aiming angle of the scanner.  ▶ The hardware components (mount, connectors and trigger) can be removed from the fabric hand wrap and re-inserted in a new hand wrap, reducing recurring costs in comparison to competitive mounts with integrated electronics.  ▶ The fabric hand wrap can be washed, after removal of the hardware components, to improve hygiene and reduce cross-contamination when used as a shared accessory.  ▶ Long trigger lifecycle (millions of presses).  ▶ Includes Hand Mount Adapter assembly and size/R-L hand specific Hand Wrap.  ▶ Color of stitching on Hand Wrap indicates size:  White = Small Black = Medium Blue = Large  ▶ For suggested sizing measure user's Hand Breadth (HB) - see diagram Hand Breadth (HB) - see diagram Hand Breadth (HB) - see diagram Hand Breadth (HB) accomodates a large hand with gloves, excluding thick or freezer gloves.  ▶ NOTE: Does not include charge contacts on assembly, therefore not compatible with 4-Slot Charging ShareCradle (CRD-RS51-4SCHG-01). Use 8-Slot Battery Charger (SAC-RS51-8CHG-01) or 40-Slot Battery Charger (SAC-RS51-8CHG-01) instead.	HB C C C C C C C C C C C C C C C C C C C		
SG-RS51-LNYD-01	ZEERA	Trigger Assembly - Lanyard Adapter	► Allows RS5100 to be worn around the neck or on hip. ► Charge contacts on assembly allow RS5100 to be inserted into 4-Slot Charging ShareCradle.	Retractor with Magnetic Recoil for Lanyard Adapter (SG- RS51-RLYD1-01)		
Soft Goods - Replacem	Soft Goods - Replacement items					

Part Number	Picture	Description	Notes	Required Items
SG-RS51-CMPD-05	1	Replacement Comfort Pad for Single Trigger assembly (pack of 5)	► Comfort Pad is used with Single Trigger RS5100 configurations.	
SG-RS51-STRPN2-10		Replacement Straps for Single Trigger configuration (pack of 10)	► Use with Single Trigger RS5100 configurations. ► Nylon material. ► Strap has thicker metal U pin which provides increased pull force vs. SG-RS51-STRPNY-10.	
SG-RS51-BHMT-02		Replacement Strap for Back of Hand Mount, MEDIUM size	► Replaces the strap that is included with the Back of Hand Adapter (SG-RS51-BHMT-02) ► Length of strap is 10.25" ► Provides modified Velcro design for increased durability vs. SG-RS51-BHSTP-01	

SG-RS51-BHSTP-01	Replacement Strap for Back of Hand Mount, MEDIUM size	► Replaces the strap that is included with the Back of Hand Adapter (SG-RS51-BHMT-01) ► Length of strap is 10.25"	
SG-RS51-BHSTLG-01	Replacement Strap for Back of Hand Mount, LARGE size	► Replaces the strap that is included with the Back of Hand Adapter (SG-RS51-BHMT-01) ► Length of strap is 12.25"	

	Τ					
Right Hand wrap SG-RS51-HNWPRL-01 (Large size) SG-RS51-HNWPRM-01 (Medium size) SG-RS51-HNWPRS-01 (Small size)  Left Hand wrap SG-RS51-HNWPLL-01 (Large size) SG-RS51-HNWPLM-01 (Medium size) SG-RS51-HNWPLS-01 (Small size)		Replacement Hand Wrap for Enterprise Hand Mount	► Replaces the fabric hand wrap that is included with the Enterprise Hand Mount Adapter (SG-RS51-HNMTxx-01) ► Color of stitching on Hand Wrap indicates size: Blue = Large Black = Medium White = Small  Refer to Trigger Assembly - Enterprise Hand Mount Adapter above for info on how to measure for proper Hand Wrap size.			
SG-RS51-RLYD1-01		Retractor with Magnetic Recoil for Lanyard Adapter	► Allows RS5100 units with Lanyard Adapter (SG-RS51-LNYD-01) to be worn around the neck or hip.			
Power Cords/Power Su	Power Cords/Power Supplies					
Part Number	Picture	Description	Notes	Required Items		
CBL-DC-388A1-01		DC Power Cord	► Used along with Power Supply PWR-BGA12V50W0WW to power 4-Slot Cradle and 8-Slot Battery Charger.  ► Cable length is 1.8 meters			

PWR-BGA12V50W0WW	THE PROPERTY OF THE PROPERTY O	Power Supply	► Used to power 4-Slot Cradle and 8-Slot Battery Charger.  ► 100-240 VAC,12V, 4.16A, 50W  ► Provides US DOE Level VI compliance for power efficiency.	►DC Line Cord (CBL-DC-388A1-01)  ►AC Line Cord (23844-00-00F or country specific version)
KIT-PWR-12V50W		Power Supply Kit	► Replaces PWRS-14000-148R  ► Includes Power Supply (PWR-BGA12V50W0WW) and DC Line Cord (CBL-DC-388A1-01)	►AC Line Cord (23844-00-00F or country specific version)
CBL-DC-381A1-01		DC Power Cord	► Used to power 20-Slot ShareCradle o 40-Slot Battery Charger when using Level VI Efficiency power supply (PWR- BGA12V108W0WW)	
CBL-DC-382A1-01		DC Power Cord	▶ Used with Power Supply PWR-BGA12V108W0WW to power 20-Slot ShareCradle or 40-Slot Battery Charger ▶ This cable includes a black extension release latch/clip that is needed when powering legacy non-ShareCradle design multi-slot cradles. This cable can be used instead of CBL-DC-381A1-01, if needed.  ▶ CBL-DC-381A1-01 is the preferred cable to use.	
PWR-BGA12V108W0WW	Constitution (CE)	Power Supply	► Used to power 20-Slot ShareCradle o 40-Slot Battery Charger ► 100-240 VAC, 12V, 9A, 108W ► Provides US DOE Level VI compliance for power efficiency. ► Replaces PWRS-14000-241R	►DC Line Cord (CBL-DC- 381A1-01) ►AC Line Cord (23844-00-00F or country specific version)
23844-00-00R		AC Line Cord	▶This AC Line Cord is for use in North America. See the AC Line Cords by Country TAG for comparable line cords to use in other countries.	
PWR-WUA5V12W0US (US plug style) PWR-WUA5V12W0GB (UK plug style) PWR-WUA5V12W0EU (EU plug style) PWR-WUA5V12W0AU (Australia plug style) PWR-WUA5V12W0CN (China plug style) PWR-WUA5V12W0IN (India plug style) PWR-WUA5V12W0KR (Korea plug style) PWR-WUA5V12W0KR (Korea plug style) PWR-WUA5V12W0BR (Brazil plug style) PWR-WUA5V12W0LA (Argentina/Chile/Mexico plug styles)		USB Power Supply	► Used with USB-C Cable to provide a lower cost charging solution than using a Cradle.  ► Provides higher current (2.5A) for faster charging  ► 100-240 VAC, 5 V, 2.5 A	USB-C Cable (CBL-TC2X- USBC-01) or (CBL-TC5X- USBC2A-01)
Batteries				
Part Number	Picture	Description	Notes	Required Items

BTRY-RS51-4MA-01 (single)  BTRY-RS51-4MA-10 (10 pack)  BTRY-RS51-4MA-02 (for use in India)(single battery)	Spare Standard Capacity Battery with PowerPrecision+ (480 mAh)	► Provides 10 hours run time at high scan rate (16+ scans/min) while operating at room temperature.	
BTRY-RS51-7MA-01 (single)  BTRY-RS51-7MA-10 (10 pack)  BTRY-RS51-7MA-02 (for use in India and South Korea) (single battery)	Spare Extended Capacity Battery with PowerPrecision+ (735 mAh)	▶ Provides 14 hours run time at high scan rate (16+ scans/min) while operating at room temperature. ▶ Provides 8 hours run time at high scan rate (16+ scans/min) while operating in cold temperatures (-4°F/-20°C).	