






Accessories for projector mounts

Illustration	Item	Specification	Ref.N o.
	Carrying tray	<ul style="list-style-type: none"> For projectors, players etc. Surface 32 x 32 cm Max. height 16 cm Suitable for Eco and Pro mounts Can be mounted directly on the ceiling 	5879 000 000
	Holding bracket	Set of 2 clamps for fixing the ceiling mount on tube-shaped supports (truss) with max. 30 - 70 mm diameter	5873 000 000
	Tilting joint	For fixing mounts of the Eco line, Comfort line and Premium line on sloping ceilings. Max. tilting 45°	7450 000 013


Accessories for Professional line

Illustration	Item	Specification	Ref.N o.
	Cover plate	For covering the mounting plate of the height-adjustable Pro mounts <ul style="list-style-type: none"> 2 parts, with perforated cable outlet 	7429 000 001
	Set of longer spider arms for large projectors	e.g. for Sanyo XP series, Mitsubishi KD 6600 etc., max. distance of the drill-holes on the projector: 493 mm	5883 000 001
	Adapter plate for EPSON Z series	For fixing on mounts of the Professional line (5883-xxx) and Premium line (7450-xxx)	5883 000 002

Accessories for Premium line

Illustration	Item	Specification	Ref.N o.
	2-element cover	<ul style="list-style-type: none"> white, RAL 9003 15 x 13 x 6 cm 	7450 000 010

Accessories for Comfort line

Illustration	Item	Specification	Ref.N o.
	Cover	For covering the cutout of the ceiling around the lower telescopic tube. For all Comfort mounts with height adjustment. White, RAL 9003	7429 000 003